

644.613.342.EL

Instructions how to install this 6volt electronic flasher relay

This new flasher comes in the box with a brown 6" wire plugged on to the -31 terminal on the relay. You must fold this terminal, with the wire attached down flat against the base of the relay before plugging it into the relay socket in your car. You must then take the ring terminal on this same brown wire and attach it to a good ground for the flasher to operate properly. You do Not use the small spring clamp like bracket that comes with some of these flashers. Just throw it away.

Dwb/z  
02/2005